FITTING INSTRUCTIONS

MAKE: BMW F800 GS (08-16)
PART: NITRON ADV R3 WITH HPA
PART NO: NTBKW18_

NITRON® SUSPENSION

INSTALL NOTES:

The shock should be fitted with the hose banjo (shock end) at 9 O'Clock. The hose should be fed around the rear of the shock and the reservoir secured to the right hand side frame rail using the two rubber reservoir mounts. The hydraulic preload adjuster should be mounted to the right hand side pillion footrest hanger using the supplied clamp. Secure the hose to the footrest hanger with a small zip tie.

For more information, get in contact
+44 (0)1993 849 449 | +1 (951 696-1111 | sales@nitron.com