FITTING INSTRUCTIONS

MAKE: BMW R1200/R1250 GS REAR (13-19)
PART: NITRON RACE PRO WITH HPA
PART NO: NTBKW48_

NITRON® SUSPENSION

INSTALL NOTES:

The shock should be installed with the piggyback reservoir and compression adjuster knobs facing the right hand side of the bike as shown. Refer to your manufacturers service manual for the correct torque settings.

For more information, get in contact
+44 (0)1993 849 449 | +1 (951 696-1111 | sales@nitron.com