FITTING INSTRUCTIONS

MAKE: DUCATI MONSTER 1200 (14-20)
PART: NITRON R3 WITH HPA
PART NO: NTBKD30_

NITRON® SUSPENSION

INSTALL NOTES:

The shock should be mounted with the remote reservoir hose exiting the shock body on the left hand side. The remote reservoir is mounted using the supplied bracket between the subframe and pillion footrest hanger as shown. Install the round black spacer on the frontmost bolt to space the footrest evenly. Secure the remote reservoir hose to the subframe using the supplied zip tie. If your shock has a hydraulic preload adjuster this should be mounted between the subframe and pillion footrest hanger on the right hand side. Install the round black spacer on the frontmost bolt to space the footrest evenly. Secure the hydraulichose to the subframe using the supplied zip tie.

For more information, get in contact
+44 (0)1993 849 449 | +1 (951 696-1111 | sales@nitron.com