



# FITTING INSTRUCTIONS

HARLEY-DAVIDSON SPORTSTER S (21-24) NITRON R1 WITH HPA



# FITTING INSTRUCTIONS

**MAKE:** HARLEY-DAVIDSON SPORTSTER S (21-24)

**PART:** NITRON R1 WITH HPA

**PART NO:** NTBKHDO5\_



## INSTALL NOTES:

If your shock has the optional hydraulic preload adjuster fitted, feed the hydraulic adjuster body through the gap in the subframe and mount in the original mounting location using the supplied bracket as shown. Use the small zip ties to secure the hose to original hose clip and run the hose over the seat key barrel to allow the sidecover to be refitted.



For more information, get in contact  
+44 (0)1993 849 449 | +1 (951) 696-1111 | [sales@nitron.com](mailto:sales@nitron.com)