FITTING INSTRUCTIONS

MAKE: KTM 390 ADVENTURE (20-24)
PART: NITRON R3 WITH HPA
PART NO: NTBKKT11_

NITRON® SUSPENSION

INSTALL NOTES:

The shock should be installed with the piggyback reservoir facing the engine and the compression adjuster knobs accessible from the right hand side of the bike. If your shock has the optional hydraulic preload adjuster, the hydraulic adjuster body should be mounted to the pillion footrest/exhaust hanger on the right hand side using the supplied bracket as shown.

For more information, get in contact
+44 (0)1993 849 449 | +1 (951 696-1111 | sales@nitron.com