FITTING INSTRUCTIONS

MAKE: YAMAHA XJ6 DIVERSION (09-13)
PART: NITRON R1 WITH HPA
PART NO: NTBKY40_

NITRON® SUSPENSION

INSTALL NOTES:

The shock should be installed so that the hydraulic preload hose exits the hydraulic cylinder on the left hand side of the shock as shown below. The hydraulic preload adjuster body should be mounted using the upper bolt that secures the rear brake master cylinder. Secure the hydraulic preload hose to the rear brake hose with the supplied zip tie.

For more information, get in contact
+44 (0)1993 849 449 | +1 (951 696-1111 | sales@nitron.com