NITRON®
SUSPENSION

FITTING INSTRUCTIONS

YAMAHA MT 09/ XSR900 (13-17) NITRON R3 WITH HPA

ISSUE NO. 3

FITTING INSTRUCTIONS

MAKE: YAMAHA MT 09/ XSR900 (13-17)
PART: NITRON R3 WITH HPA
PART NO: NTBKY55_

NITRON® SUSPENSION

INSTALL NOTES:

The shock should be mounted with the remote reservoir hose exiting on the underside of the shock body. Route the hose around to the left hand side and mount the remote reservoir using the supplied bracket between the subframe and pillion footrest hanger as shown. The hydraulic preload adjuster should be fitted between the right hand side pillion footrest hanger and subframe using the supplied bracket. Secure the hose to the subframe with the small zip ties.

For more information, get in contact
+44 (0)1993 849 449 | +1 (951 696-1111 | sales@nitron.com