NITRON®
SUSPENSION

FITTING INSTRUCTIONS

APRILIA TUAREG 660 (22-25) NITRON ADV R3 WITH HPA

ISSUE NO. 2

FITTING INSTRUCTIONS

MAKE: APRILIA TUAREG 660 (22-25)
PART: NITRON ADV R3 WITH HPA
PART NO: NTBKA17_

NITRON® SUSPENSION

INSTALL NOTES:

The shock should be installed with the HPA hose exiting on the right hand side of the shock body. Route the hose along the top subframe rail and then behind the pillion footrest hanger. The HPA body is mounted to the exhaust hanger bolt with the supplied bracket. Use the two adhesive zip tie bases on the underside of the seat plastics to secure the hose with zip ties and two zip ties to secure the hose on the top subframe rail.

For more information, get in contact
+44 (0)1993 849 449 | +1 (951 696-1111 | sales@nitron.com