FITTING INSTRUCTIONS

MAKE: BMW S1000RR (12-14)
PART: NITRON R3 WITH HPA
PART NO: NTBKW22_

NITRON® SUSPENSION

INSTALL NOTES:

The hydraulic preload adjuster should be mounted using the rearmost pillion footrest hanger bolt with the supplied bracket as shown.

For more information, get in contact
+44 (0)1993 849 449 | +1 (951 696-1111 | sales@nitron.com