FITTING INSTRUCTIONS

MAKE: YAMAHA MT 09/ XSR900 (13-17)
PART: NITRON R1 WITH HPA
PART NO: NTBKY55_

NITRON® SUSPENSION

INSTALL NOTES:

Install the shock so that the hose exits the hydraulic cylinder on top of the shock on the left hand side. The hydraulic adjuster body can then be fed around to the right hand side unobstructed. Secure the hose with the supplied zip tie. The hydraulic preload adjuster body should be fitted using the supplied bracket between the rear footrest hanger and subframe.

For more information, get in contact
+44 (0)1993 849 449 | +1 (951 696-1111 | sales@nitron.com